LENSGO

COB 40W

USER'S MANUAL

ヴィンテージ・ハンドヘルド・ランプ 使用说明书

MODEL: **40H**

INSTRUCTIONS | NOTES

This manual provides information on the proper use and storage of the product and accessories, and assists the user in dealing with questions about their use and in understanding the safety precautions to be taken.

PLEASE READ CAREFULLY

When handing the product over to another person, be sure to include this manual, heed all warnings and follow all instructions in the manual.

2 YEAR WARRANTY DESCRIPTION

The warranty, which applies to all purchasers from our authorised dealers, covers any defects caused by production, as well as failures in the course of normal use, excluding physical damage, natural disasters (fire, flood, earthquake lightning, etc.) and chemical corrosion, unauthorised repairs, replacement of components during handling, collisions at the site of the installation and other failures due to human or force majeure reasons. and damage, or the manual Any malfunction caused by acts expressly prohibited by the instruction manual

ACCESSORY DESCRIPTION

Mobile phone clip, camera frame, hand screws and other accessories are consumables (not in the 2-year warranty), after use, please confirm whether there is aging, damage and other conditions of this phenomenon is normal wear and tear, in order to use the convenience of please contact the dealer in time to buy new parts replacement!

MAINTENANCE METHODS

Please use a soft sponge, soft cloth, dry cloth to clean the product regularly, do not use bleach, wire ball wipe, wipe clean and keep the product dry.

For more information on LENSGO product features,
Please visit **WWW.lensgo.net**

INSTRUCTIONS

40H is a COB 40W, dual colour temperature 2700-7000K adjustable, colour rendering index ⩾96, burst flash, along the vintage flash styling of the constant light, mobile phone / camera can be used!

- **2700K - 7000K DUAL COLOUR TEMPERATURE**
  Knob-adjustable infinitely dimmable, high display index to restore true colours
- **WITH SILICONE SOFTBOX**
  The soft light amplitude is suitable, the light is soft and not harsh
- **0%-100% BRIGHTNESS ADJUSTABLE**
  Turning the adjustment knob, the brightness change range is 0-100%.

COB 40W

SPECIFICATION

MODEL:	40H
TYPE:	COB 40W
Colour temperature:	2700K-7000K
Jadeite thumb ring:	⩾ 96
Batteries:	4 x 18650 14.8V
Charging Voltage:	12V 2A
Duration of use:	Approx. 1 hour (when used at maximum brightness)
Adjustment range:	Brightness adjustment 0%-100%
Number of beads:	Total 192 pcs
Bead Voltage:	36 ~ 68V
Bead Current:	1100mA

OPERATING INSTRUCTIONS

Product structure diagram.



❶ On / Off
Long press to switch on/off, double tap to enter FX mode
Push to switch between warm and cold light

❷ Indicator light
Blue light when switching on full power, red light when power is low

❸ knob
Turn the knob clockwise to adjust the brightness of the light, and turn it anti-clockwise to dim the brightness.
Double-click the knob to enter the colour temperature mode, adjust the cold light in the clockwise direction, adjust the ambiguous light in the anti-clockwise direction, double-click to exit after the adjustment is complete.

❹ DC charging port
Charging voltage 12V 2A

❺ 1/4 screw hole
Mountable device with 1/4 thread interface

INSTRUCTIONS | BRACKET DESCRIPTION



❶ 1/4 screw hole, fits❺, locks bracket to light.
❷ Expandable to mount any tripod device with 1/4 screws
❸ With❻ hand screws, the camera can be mounted to the bracket with a locking mechanism.
❹ Expandable to mount any tripod device with 1/4 screws

⚠WARNING

- Keep this product out of the reach of children in a safe place.
- Please use the original parts correctly.
- Before each use, please be sure to check whether the installation is stable, to prevent accidents during use.
- Store in a cool, dry place, prohibit exposure to the sun, waterproof

Camera Usage

⚠WARNING

- 1: Align the bracket to the bottom of the light first and tighten the screw by hand
- 2: The camera is set up on the bracket and screwed in by hand.
- 3: Can be expanded to install any equipment with 1/4 interface according to the use of demand

Before use, please carefully check whether the installation is stable or not.

LENSGO

If you have any questions, suggestions, or would like to share the wonderful works created with this light, please feel free to reach out to us through the channels below.

www.lensgo.net
@LensgoOfficial
Lensgotech
Lensgo_official

LENSGO



USER'S **MANUAL**

MODEL: **40H**

MANUFACTURER: SHENZHEN LYNCA PHOTOGRAPHIC EQUIPMENT CO.,LTD
Add: 3/F, Building Gaorong, No. 12 XinmuXinyuan Industrial Park, Pinghu Street, Longgang District, Shenzhen, Guangdong, China
Web: http://www.lensgo.net/
Exebutive Standard: Q/LYJ004-2018
Facebook: Lensgotech
Made in China

INSTRUCTIONS | LIST OF ACCESSORIES

You will receive the following accessories (subject to the options available at the time of your order)

❶ Handheld light
❷ Silicone softbox
❸ Mobile phone clip (horizontal / vertical)
❹ Battery charger
❺ Camera bracket (mobile phone holder can be mounted)
❻ Hand screw X2

MODEL: **40H**

Please read these instructions carefully before using this product

WHEN USING, DO NOT SHINE THE LIGHT TO THE EYES **TO PREVENT EYE BLURRING**

INSTRUCTIONS

1: 2700K-7000K colour temperature adjustment
Double-click❸ to enter the colour temperature mode, adjust the cold light in the direction of the clock, adjust the ambiguous light in the direction of the counterclock, double-click to exit after the adjustment is completed

2: 0-100% brightness adjustable
Turn❸ clockwise to adjust the brightness of the light, this time the light will be in accordance with the % ratio of light, turn counterclockwise to dim the brightness

3: 8 lighting effects
Double click❸ to enter FX mode

4: Push to switch between warm and cold light
Click❸ for instant switching

5: Detecting power
Off state, click❸to detect the power, display the current power % position, if all do not light up, please charging

When charging❹ press % sequential flashing light, full of blue light always on

Charging | Fully charged | ❹ DC charging port

FX MODE

8 different effects, press to switch, double click to exit after setting up

LIGHTNING MODE	TV MODE	BAD BULB MODE
SOS MODE	BURST MODE	CANDLELIGHT MODE
PULSE FLASH MODE	HIGH AND LOW BEAM BULBS	

INSTRUCTIONS

Mobile phone usage

Adjustable horizontal/vertical racket

⚠WARNING

- 1: Align the bracket to the bottom of the light first and tighten the screw by hand
- 2: The camera is set up on the bracket and screwed in by hand.
- 3: Can be expanded to install any equipment with 1/4 interface according to the use of demand

Before use, please carefully check whether the installation is stable or not.

⚠WARNING

- Do not touch the COB lamp beads with your hands to prevent burning hands
- This product is a precision instrument, please avoid dropping it when using it.
- Contact authorised service personnel when repairs are required
- It is recommended to use the original LENSGO cables. Any damage to this product caused by the use of non-Longsong original accessories is not covered by our warranty. Any damage to this product is not covered by our warranty.
- Please clean the product with a soft, dry cloth.
- This specification is based on our rigorous testing. Design and specifications are subject to change without notice
- Please keep it in a safe place, read this instruction manual carefully, and observe all precautions
- Before use, please check whether the installation is stable, to prevent accidents during use.
- Please switch off the product after charging, in order to protect the safety and life of the battery, try not to use it during charging. use the product during charging.
- Do not cover the ventilation holes when using the silicone softbox.

CERTIFICATE OF CONFORMITY

PRODUCT NAME:
MODEL:
INSPECTION DATE:
INSPECTOR:

QUALIFIED